WELD METAL, TOOLS & ACCESSORIES

FLINT IGNITOR 38-0309-00

The 38-0309-00 Flint Ignitor is used to ignite the starting powder. Each mold that is sold with a frame has a Flint Ignitor included.

Replacement flints are available upon request. Part #38-0309-01.



FLINT IGNITOR EXTENSION 38-0904-00

The 38-0904-00 Flint Ignitor Extension allows the installer to stand 36" from the mold. Flint Ignitor is included.

ELECTRONIC FLINT TRIGGER 38-8253-00

thermOweld's new Electronic Flint Trigger is designed to ignite the starting powder by generating time delayed sparks of 5, 10 or 15 seconds, igniting the starting powder on top on the mold. The Trigger mount to the side of the any size mold with a magnet.



lgnitors æd per box

in box

WELD METAL, TOOLS & ACCESSORIES

EZ Lite Remote® Electric Ignition System

Mission Critical jobs require the versatility of thermOweld's EZ Lite Remote[®] System so you can finish without delays. Our remote system is the only system that gives you 2 ignition options so you can finish your job on time.

- Use your Flint Ignitor or the EZ Lite Remote[®] and never be stuck out on the job!
- Have 100% confidence that you will get your connections done when you want!
- Reliable ignitor 100% guaranteed to ignite
- Use with existing thermOweld® EZ Lite® Mold and Weld Metal
- Uses 4 Alkaline "D" size batteries (we recommend a high quality brand battery such as Duracell[®] or Energizer[®]).

EZ Lite Remote [®] Electric Ignition Catalog #'s			Pre-packaged Weld Metal with Ignit		
Catalog #	Description	Time	Standard	Cast Iron	Packed J
38-EZLT-RU	EZ Lite Remote® Unit, ready to use with batteries installed at the factory	SDS			box
38-EZLT-15	EZ Lite Remote® Unit with 15 ft lead, ready to use with batteries installed at the factory	3	TW15EZ	-	20
			TW25EZ	TW25CIEZ	20
38-EZLT-IG	(10) 38-EZLT-IG EZ Lite Remote [®] Ignitors for use with existing thermOweld [®] EZ Lite [®] Molds and weld metal on your shelf, in your truck or at the job site.	SDS	TW32EZ	TW32CIEZ	10
			TW45EZ	TW45CIEZ	20
38-EZLT-SK	Starter Kit complete with; (1) 38-EZLT-RU EZ Lite Remote [®] Unit, ready to use with batteries installed at the factory (20) 38-EZLT-IG EZ Lite Remote [®] Ignitors for use with existing thermOweld [®] EZ Lite [®] Molds and weld metal on your shelf, in your truck or at the job site	SDS	TW65EZ	TW65CIEZ	20
			TW90EZ	TW90CIEZ	10
			TW115EZ	TW115CIEZ	10
			TW150EZ	_	10
			TW200EZ	_	10
38-EZLT-SS	EZ-Lite Remote adapter for Single Shot Molds	SDS	TW250EZ	_	10
38-EZLT-CA	6 ft. Replacement lead	3	TW500EZ	_	10
38-EZLT-CX	15 ft. Replacement lead	3	thermOweld® Weld Metal is sold in b quantities only		
38-EZLT-CY	20 ft. Replacement lead	3			
38-EZLT-CW	Cold Weather Kit	2			



EZ Lite Remote[®] Cold Weather Kit Instructions

When using thermOweld[®]'s EZ Lite Remote[®] in temperatures below 32^o F (freezing) we recommend using our Cold Weather Kit 38-EZLT-CW. The Kit includes 4 adapters and 12 AA Batteries (we recommend a high quality brand battery such as Duracell[®] or Energizer[®]).



WWW.THERMOWELD.COM · 1-800-558-1373 · +1 (918) 627-5210